



# ALLIANCE HOBBY

36 S ARCH AVE UNIT 2283  
ALLIANCE OH 44601-6315  
sales@alliancehobby.com  
(330) 356-8090

## Crosman Shoulder Stock Quick Release Hardware

- 1) Remove grip frame from gun.
  - a. Use a #2 Square bit or, less preferably, a flat head screwdriver to remove the front grip frame screw (ahead of the trigger) and the rear screw (all the way at the rear).
  - b. I use the #2 from this kit:
    - i. <http://www.amazon.com/gp/product/B000E7ZMTI>
    - ii. I also sell a similar #2 driver in my Tool Kit (available on my site).
- 2) Drop the bushing into the hole directly in front of the rear screw hole. The flange of the bushing will rest against the grip frame and it will be like a cup.
  - a. Insert spring into bushing. It will protrude slightly, just like the trigger safety spring above the trigger itself.
    - i. Pro tip: Lose either spring? They're the same part number and I have hundreds available.
- 3) Reassemble grip frame to gun so that both quick release spring and trigger spring compress against the main tube (this is what provides the quick release action).
- 4) Attach shoulder stock. When the parts are brand new, it can take a surprising amount of force to lock it in place, and an equally surprising amount of pressure to press the bushing upward, to remove the stock.

Quick-Release Hardware for  
Crosman 1399 Shoulder Stock

